

ICSSC-2 INSTALLATION INSTRUCTIONS ATTACHMENT TO CONCRETE STRUCTURE


File No. ISOIN-ICSSC-2-100-4500

Date:06/14/2018

ICSSC-2-100-4500 Restraint/Isolators are Pre-Compressed products. Isolator Top plate is under pressure caused by compressed springs. The following steps must be followed carefully for proper installation:

1. Do not remove Spacers/Shipping Blocks from isolators until step #10 as they are the key indicators for proper adjustment on springs

- 2. Refer to submittal package prepared by ISOTECH Industries and locate each isolator based on model# and identification tag provided
- 3. Secure Isolators to the supporting concrete structure using (4) four or (6) six sets of seismically rated concrete anchors.
- a. Refer to submittal package for anchor size, edge distance anchor embedment and concrete structure thickness
- 4. Mark isolator anchor holes on concrete structure and follow anchor manufacturer's instructions on hole preparation, hole cleaning procedures, anchor installations and required torque value on anchor nuts- secure each isolator to concrete structure
- 5. Use crane, gantry or other proper lifting machine to elevate equipment and/or equipment supporting structure



PROJECT INFORMATION		EQUIPMENT INFORMATION		Canada location	USA Location
Customer:		Туре:		35 Silton Road	3021 E Coronado St.
Project:		Qty Required:		Woodbridge ON L4L 7Z8 CANADA	Anaheim, CA.,92806 U.S.A
Drawing No:		Operating Weight:		T: 905-856-5001	T: 949-788-2930
Notes:			Tool free : 1-888-831-3311 www.isotechindustries.com		







ICSSC-2 INSTALLATION INSTRUCTIONS ATTACHMENT TO CONCRETE STRUCTURE

File No. ISOIN-ICSSC-2-100-4500


Date:06/14/2018


6. Carefully lower the equipment and/or equipment supporting structure and properly locate it on top of isolators. Use (4) four sets of 1/2" dia. bolts, nuts and washers to secure the equipment and/or equipment supporting structure to each isolator







7. Ensure isolator top plate is fully covered by equipment and/or equipment supporting structure as shown in pictures below. For installations where less than 80% of isolator top plate is covered, refer to Step 11 shown on the third page:





8. Loosen the two Lock Nuts located inside each stanchion as shown in the picture and move it down to have 1/8" gap between washer and bottom of Reinforced Rubber Washer





PROJECT INFORMATION	EQUIPMENT INFORMATION	Cana
Customer:	Туре:	35 Si
Project:	Qty Required:	Wood L4L 7
Drawing No:	Operating Weight:	T: 90
Notes:		

ada location **USA Location**

Silton Road 3021 E Coronado St. odbridge ON Anaheim, CA.,92806 7Z8 CĂNADA U.S.A 05-856-5001 T: 949-788-2930



Tool free: 1-888-831-3311 www.isotechindustries.com

COPYRIGHT: UNLESS OTHERWISE AGREED OR STATED IN WRITING, ALL INFORMATION AND DESIGNS DISPLAYED WITHIN ARE ALL THE PROPERTY OF ISOTECH INDUSTRIES INC. AND MAY NOT BE DUPLICATED OR DISTRIBUTED OUTSIDE OF ISOTECH INDUSTRIES INC. WITH THE EXCEPTION OF AUTHORIZED PERSONS WITH LEGITIMATE NEED TO KNOW WHO BY THE USE OF THIS RECOGNIZE ISOTECH INDUSTRIES INC. OWNERSHIP AND WILL COMPLY TO MAINTAIN THIS INFORMATION AND DESIGN IN STRICT CONFIDENCE.




ICSSC-2 INSTALLATION INSTRUCTIONS ATTACHMENT TO CONCRETE STRUCTURE


File No. ISOIN-ICSSC-2-100-4500

Date:06/14/2018

9. With Spacers/ Shipping Blocks in place, follow star pattern sequence shown below and turn Spring Adjustment Bolt one or two turns on each isolator. DO NOT turn Spring Adjustment Bolt more than two turns at a time



- 10. Follow Star Pattern Sequence until Spacers/ Shipping Blocks can be moved easily
- 11. Installations where Equipment supporting structure or equipment footing covers les than 80% of isolator top plate:
- Add a reinforcing plate, with the same dimensions of isolator top plate, on top of isolator top plate as shown below:



• Continue Installation by following Step 8 through 10

PROJECT INFORMATION	EQUIPMENT INFORMATION	Canada location	USA Location	
Customer:	Type:	35 Silton Road	3021 E Coronado St.	
Project:	Qty Required:	Woodbridge ON L4L 7Z8 CANADA	3021 E Coronado St. Anaheim, CA.,92806 U.S.A T: 949-788-2930	
Drawing No:	Operating Weight:	T: 905-856-5001		
Notes:		Tool free : 1-888-831-3311 www.isotechindustries.com		