

IPGR - ISOTECH RISER GUIDES

File No. : ISOCS-IPGR-2.5-10


Date: 15/05/20

1 × D


ISOIN-IPGR-2.5-10, Installation Instructions Document, to be Reviewed for Installation

SPECIFICATIONS: IPGR ISOTECH RISER GUIDE DIMENSIONS


	FOR MAX. 1.5 INSULATION														
NOM. PIPE SIZE	THERMAL MOVEMENT	L		L1		W		W1		ОН		Н		А	
D (in)		in	mm	in	mm	in	mm	in	mm	in	mm	in	mm	in	mm
21/2	MAX. 4" AXIAL MOVEMENT	8 3/4	222	7 ½	191	3	76	5 %	137	4 1/4	108	7 ½	191	7∕16	11
3		10	254	8 %16	217	3	76	6	152	4 3/4	121	8 ½	216	7/16	11
4		10 ¾	273	9 1/4	235	3	76	6 ½	165	5 ¾16	132	9 %	238	%16	14
6		13 1/4	337	11 1/4	286	4	102	7 1/8	181	6 1/4	159	11 %16	294	11/16	17
8		15 1/8	384	13 1/4	337	4	102	8 1/8	206	7	178	13 %	340	11/16	17
10		20 %	517	18 %	467	6	152			10 3/16	259	16 %16	421	11/16	17



PIPE GUIDE SPACING									
D (in)	MAX. DISTANCE FROM EXPANSION JOINT TO 1ST PIPE GUIDE OR PIPE ANCHOR	FROM EXPANSION JOINT TO 1ST PIPE GUIDE OR PIPE GUIDE OR PIPE GUIDE							NG TO
	4 x D	14 x D	50 psi	100 psi	150 psi	200 psi	250 psi	300 psi	350 psi
21/2	10 in	24 in	32 ft	23 ft	17 ft	16 ft	14 ft	13 ft	12 ft
3	12 in	42 in	38 ft	27 ft	22 ft	19 ft	17 ft	16 ft	15 ft
4	16 in	56 in	52 ft	37 ft	31 ft	27 ft	24 ft	22 ft	20 ft
6	24 in	84 in	67 ft	47 ft	39 ft	34 ft	32 ft	28 ft	26 ft
8	30 in	112 in	86 ft	62 ft	51 ft	44 ft	40 ft	36 ft	34 ft
10	40 in	140in	100 ft	75 ft	60 ft	52 ft	50 ft	45 ft	40 ft



С									
D	in	mm							
2 ½	5∕16	8							
3	5/16	8	CONTACT FACTORY FOR						
4	5/16	8	OTHER PIPE SIZES						
6	¹³ ⁄16	21							
8	13/16	21							









Fig.1









Pipe Guide Specifications:

- · ISOTECH Pipe Guides' finish is specialty epoxy electrostatic paint to prevent galvanic corrosion when installed on Stainless Steel and Copper pipes
- ISOTECH Pipe Guides are designed for both floor mount and wall mount installations. Use 3/8" anchors for size $2\frac{1}{2}$ and 3 in, $\frac{1}{2}$ " anchors for size 4 and $\frac{1}{2}$ " anchor for size 6 and 8 in for securing pipe guides to building
- ISOTECH Pipe Guides are designed to support 15% of pipe anchor load; the above table must be used for pipe guide distance from Expansion joint.

Instalation Instructions:

- Step 1: Follow Fig.1 and install the two spider half clamps on pipe using long 3%" bolts provided
- Step 2: Follow Fig.2 center the outer shells around pipe spider clamp, leave 1/8" gap between spider clamp tabs and outer shell
- Step 3: Follow Fig.3 and connect outer shell halves together using short 3%" bolts provided. Use (2) bolts for size $2\%, 3\,\&\,4$ and (4)bolts for size $6\,\&\,8$ as provided in pipe guide box
- Step 4: Center outer shell with pipe and ensure $\frac{1}{8}$ " gap between spider clamp tabs and outer shell, then anchor pipe guide to building structure
- Step 5: Install pipe guides per distances specified on the above table according to pipe size and in-line pressure.

PROJECT INFORMATION		EQUIPMENT INFOR	Canada location		
	Customer:		Туре:		35 Silton Road
	Project:		Qty Required:		Woodbridge ON L4L 7Z8 CANADA
	Drawing No:		Operating Weight:		T: 905-856-5001
	Notes:				Too

3021 E Coronado St. Anaheim, CA.,92806 U.S.A T: 949-788-2930

USA Location



Tool free: 1-888-831-3311 www.isotechindustries.com

COPYRIGHT: UNLESS OTHERWISE AGREED OR STATED IN WRITING, ALL INFORMATION AND DESIGNS DISPLAYED WITHIN ARE ALL THE PROPERTY OF ISOTECH INDUSTRIES INC. AND MAY NOT BE DUPLICATED OR DISTRIBUTED OUTSIDE OF ISOTECH INDUSTRIES INC. WITH THE EXCEPTION OF AUTHORIZED PERSONS WITH LEGITIMATE NEED TO KNOW WHO BY THE USE OF THIS RECOGNIZE ISOTECH INDUSTRIES INC. OWNERSHIP AND WILL COMPLY TO MAINTAIN THIS INFORMATION AND DESIGN IN STRICT CONFIDENCE.