




IOSBT-2, 2" DEFLECTION OPEN SPRINGS INSTALLATION INSTRUCTIONS

1. Refer to submittal package prepared by ISOTECH Industries and locate each isolator based on model # and identification tag provided
2. Use temporary support, such as shims, to get operating height required and lower equipment on Supporting strut
3. Secure equipment, pipe or ductwork on supporting strut as shown. Use U-Bolts, Straps or weld as appropriate for securement
4. Follow star pattern sequence shown below and turn leveling nut clockwise to free equipment from temporary support. Do not turn leveling



STAR PATTERN ORDER: 1, 4, 2, 3, & 1



| PROJECT INFORMATION | | EQUIPMENT INFORMATION | | Canada location | USA Location |  |
|---------------------|--|-----------------------|--|--|---|---|
| Customer: | | Type: | | 35 Siltan Road Woodbridge ON L4L 7Z8 CANADA T: 905-856-5001 | 3021 E Coronado St. Anaheim, CA.,92806 U.S.A T: 949-788-2930 | |
| Project: | | Qty Required: | | | | |
| Drawing No: | | Operating Weight: | | | | |
| Notes: | | | | | | |

COPYRIGHT: UNLESS OTHERWISE AGREED OR STATED IN WRITING, ALL INFORMATION AND DESIGNS DISPLAYED WITHIN ARE ALL THE PROPERTY OF ISOTECH INDUSTRIES INC. AND MAY NOT BE DUPLICATED OR DISTRIBUTED OUTSIDE OF ISOTECH INDUSTRIES INC. WITH THE EXCEPTION OF AUTHORIZED PERSONS WITH LEGITIMATE NEED TO KNOW WHO BY THE USE OF THIS RECOGNIZE ISOTECH INDUSTRIES INC. OWNERSHIP AND WILL COMPLY TO MAINTAIN THIS INFORMATION AND DESIGN IN STRICT CONFIDENCE.